

CONSTRUCTION LASER

# DL 50

Long range (1000m), Tough (rental standard)  
Single axis slope, Water proof (IP56)



 **AMA LASER**  
Made in Sweden  
[www.amalaser.com](http://www.amalaser.com)

Almost 30 years ago AMA Laser introduced the worlds first fully automatic, fully water proof diode laser. The DL 150. Many of which are still being used on construction sites around the world.

We at AMA Laser believe that all the products that we design and build should be simple to use, fit for purpose and uncompromising in construction. If we can make products that last a life time then with a bit of luck we will have customers for life.

30 years on we are now pleased to introduce the next generation DL50. With single grade capability and high spec long life rechargeable batteries.



The AMA D5 is a 5 channel, heavy duty laser detector with both LCD and LED displays. Incorporating audio signals for on and off grade.



The DL50 is easy to set up with high performance built to last.



Tilt function, Push the DL50 too hard and it will need to be restarted. Your set up height will need to be rechecked. No chance of height errors.



When you need extreme distance the DL 50 is ready. visibility under difficult measurig conditions.

### Technical Specification:

- ✓ 500M radius, operating range
- ✓ 600 and 1200 rpm
- ✓ Water proof IP56
- ✓ +/-5mm /100M horizontal accuracy
- ✓ Power source, NI-Mh four C-cell
- ✓ Run time 65 hrs/charge
- ✓ Laser beam: visible 670 nm.
- ✓ Tilt: Normally active, can be disabled
- ✓ Operating temperature range -20 to +60° C
- ✓ Weight 1,9 KG



Variable RPM



manually single sloop